



Notes:

1. High leg on Delta services must be marked with orange tape.
2. 240/480V and 277/480V services require a disconnect switch on the source side of the meter socket. See drawings.
3. All 120/240V and 120/208V services require a disconnect switch or main breaker on the load-side of the meter socket. See drawings
4. All sockets, except for single phase 200 amps or less, shall have an integrated manual mechanical gang operated bypass switch.
5. Load and supply wires shall not cross in the meter socket (Section 11.1.2.7)

**WIRING DIAGRAM FOR OVERHEAD
SELF CONTAINED METERS**

DRAWING 11.8-1

August 2010
NOT TO SCALE

